


BURNING A DVD/CD ON APOLLO AND ZEUS DVR'S

INSERT BLANK DVD+R/CDR , OR USB PEN DRIVE (PLEASE NOTE : PEN DRIVE MUST BE PRE FORMATTED IN FAT32)

ON LIVE VIEW RIGHT CLICK MOUSE BUTTON

HIGHLIGHT **SEARCH** AND PRESS LEFT MOUSE BUTTON



Left Click Here

YOU WILL SEE FOLLOWING SCREEN APPEAR

ANGLE SECURITY




Figure 1 Search

ON THE LEFT HAND SIDE OF THE SCREEN THERE IS A **CLOCK**, LEFT CLICK **CLOCK**

CHOOSE DATE LEFT CLICK

MOVE TO NEXT SECTION THAT IS FULL OF ZEROS, USING LEFT CLICK INSERT THE **START TIME** OF EVENT

MOVE TO NEXT SECTION (**SEARCH TYPE** - NORMALLY SAYING ALL) AND CHOOSE WHAT TYPE OF INFORMATION YOU WOULD LIKE TO PLAYBACK – IE.

MD = MOTION DETECTION

ALL = REGULAR

ALARM = ALARM

ALARM/MD = ALARM/MOTION DETECTION

MOVE TO THE NEXT SECTION (**CAMERA SELECT 1**) AND CHOOSE THE CAMERA FROM THE DROP DOWN LIST

MOVE TO THE **SEARCH ICON** AND LEFT CLICK

FILES WILL APPEAR IN THE **FILE LIST WINDOW**

TO PLAY -- DOUBLE CLICK LEFT MOUSE BUTTON ON REQUIRED FILE IN THE **FILE LIST WINDOW**

TO BURN – TICK REQUIRED FILE IN THE **FILE LIST WINDOW**

CLICK **BURN ICON**

MAKE SURE YOU HAVE A TICK NEXT TO THE CORRECT BACKUP DEVICE

(IDE CDRW) IF USING THE DVD DRIVE

(USB DISK) IF USING THE USB PEN DRIVE (PLEASE NOTE : PEN DRIVE MUST BE FORMATTED IN FAT32 BEFORE DVR WILL RECONISE)

ONLY ONE SAVE DEVICE SHOULD BE TICKED

ENSURE REQUIRED FILE ALSO HAS A TICK

CLICK **BACKUP**

